

Vertebralplasty

Application Examples: compression fracture, pre vertebralplasty

Sequence	FoV	Thickness	Gap
SAG T1	45CM	3MM	0.5MM
SAG T2	45CM	3MM	0.5MM
SAG STIR	45CM	3MM	0.5MM
AX T2 AT LEVEL OF FRACTURE	20CM	4MM	0.5MM
AX T1 AT LEVEL OF FRACTURE	20CM	4MM	0.5MM